




按住MUNE+开机进入hcc下载
 键盘键，主界面UP、down为音量+、-，进入菜单后为up/down



0.96 UN-2864KSWPG16确认液晶

